

Bennett Pacific Series

DIN (Dispenser Identification Number)



Box 1 (Unit of Measure)[Field Position #9]
 Electronic Pump w/eCal Meters: G=Gallon, L=Liter, or I=Imperial Gallon
 Electronic Pump w/mCal Meters: A=US Gallon, B=Liters, C=Imperial Gallon

23 Graphics. Country-Language-Suffix Number. Assigned at factory during entry of the order. These, if used, supercede the Lower Door Graphics Selection. Do not enter data into these data fields. **Reserved for Bennett Order Entry.**

22 Credit Network. 3 letters in fields 20, 21, 22

21 Credit Network. 3 letters in fields 20, 21, 22

20 Credit Network. 3 letters in fields 20, 21, 22

19 Future Use. Leave "N" for now.

18 Pump Security. N=Standard

17 Hose Retractor. N=None, H=Hose Retractor

16 Cash Acceptor. N=No Cash Acceptor, C=Cash Acceptor

15 Filter Type. S=Spin On (Standard), P=Petrodyme

14 Speaker Option. N=None, S=Speaker, C=Speaker w/Call Button

13 Number of Electrical Conduits. 1 (standard) or 2 (optional)

12 J-Box Option. N=None, J=J-Box

11 Vapor Recovery. N=None, A=Healy System Ready, B=Balanced, H=Healy Factory, F=Healy Incon Factory, G=Healy Veeder Factory

10 Valance. N=No Valance, V=Valance

9 Unit of Measure. See Box 1

8 Fuel. S=Standard Fuels, A=Alcohol (E-85 Product), Note: cannot have both options in one dispenser

7 Payment Options: N=None, L=Local Preset, P=Local Preset with Printer, C=Bennett Credit, D=Bennett Debit/Credit Reader, V=VeriFone Secure PumpPAY, F=Fiscal

6 Fueling Positions. 1=One Side, 2=Two sides

5 Blender Option. N=Non-Blender, M=Mixer, B=Blender

4 Number of Hose Outlets. 1

3 Number of Products. 1, 2, 3, or 4

2 Price Tiers. 1=1price tier, 2=2 price tier

1 Dispenser Series. Always "1"



Note: Order the valance canopy as a separate order line item.